

Rechargeable Prodder 31 cm Shaft

Need help? We're here for you.

If you have questions or need advice, our friendly team is just a call or click away.

New Zealand: Shoof International Ltd. 224 Laurent Road North, Cambridge 3493, New Zealand. Ph 0800 800 801

Australia: Shoof International Pty Ltd.

1 International Square, Tullamarine VIC 3043,
Australia. Ph 1800 121 801

Chile: Shoof International Chile Ltda. Regidor Gustavo Binder 1147, Bodega 3 y 4, Osorno, Chile, Ph 800 600 000

Shoof - we make caring for animals easier.

Shoof and Taragate by Shoof are trademarks of Shoof International Ltd

31001 Code: 224 042





Rechargeable Prodder

31 cm Shaft

- · Flexible shatter-proof shaft
- · High shock performance
- Safety switch to prevent accidental discharge
- No residual shock
- Rechargeable 12 v and 240 v





Instructions for the Taragate Rechargeable Prodder

I. Preparation before using:

- 1. Follow the user's manual when you operate a prodder.
- Choose the right shaft that allows you to keep a safe working distance from all livestock.
- 3. Check that all connections are clean and dry.
- 4. Insert the shaft into the handle and tighten the lock nut.
- Check that all the batteries are installed properly in the battery pack and that all connections are firmly fastened.

II. Operational Instructions:

- Turn the switch of the prodder to the "ON" position. Turn it "OFF" when not in use, to prevent accidental shock.
- To operate the prodder, press the button on the prodder, touch the rear of the animal with the two electrodes, the prodder releases effective electric shock, release the button. A light touch makes the most effective results.
- Because of potential for increase in intensity, operate the prodder carefully when the animals are wet.

III. How to charge the battery pack:

- Charge directly, you needn't take out the battery pack. Plug the Taragate electronic charger into the battery pack, connect to the AC power.
- The rechargeable battery is nickel cadmium (bubbling nickel). It has superior over-charge or discharge endurance, superior leakage resistance and extremely safe. Its cycle life is over 500 cycles under normal operations.
- The charger light will glow red when charging. When it turns green the unit is fully charged. Charging will take 8 - 10 hours.

IV. Notes for use:

- 1. This product is for farm animal use only. Keep out of reach of children.
- 2. The unit can be washed with water.
- 3. Do not submerge.
- 4. Do not discharge while in water.
- 5. Waterproof (IP45) under normal use.



The waterproof connections are as follows:

A, B, C & D: Rubber rings (waterproof connections)

E: Screw





Rechargeable **Prodder** 57 cm Shaft

Need help? We're here for you.

If you have questions or need advice, our friendly team is just a call or click away.

New Zealand: Shoof International Ltd. 224 Laurent Road North, Cambridge 3493. New Zealand, Ph 0800 800 801

Australia: Shoof International Ptv Ltd. 1 International Square, Tullamarine VIC 3043, Australia Ph 1800 121 801

Chile: Shoof International Chile Ltda. Regidor Gustavo Binder 1147, Bodega 3 v 4. Osorno, Chile, Ph 800 600 000

Shoof - we make caring for animals easier. www.shoofInt.com

Shoof and Taragate by Shoof are trademarks of Shoof International Ltd

Shoof Code: 224 643









Rechargeable **Prodder**

57 cm Shaft

- Flexible shatter-proof shaft
- High shock performance
- Safety switch to prevent accidental discharge
- No residual shock
- Rechargeable 12 v and 240 v

Instructions for the Taragate Rechargeable Prodder

I. Preparation before using:

- 1. Follow the user's manual when you operate a prodder.
- Choose the right shaft that allows you to keep a safe working distance from all livestock.
- 3. Check that all connections are clean and dry.
- 4. Insert the shaft into the handle and tighten the lock nut.
- Check that all the batteries are installed properly in the battery pack and that all connections are firmly fastened.

II. Operational Instructions:

- Turn the switch of the prodder to the "ON" position. Turn it "OFF" when not in use, to prevent accidental shock.
- To operate the prodder, press the button on the prodder, touch the rear of the animal with the two electrodes, the prodder releases effective electric shock, release the button. A light touch makes the most effective results.
- Because of potential for increase in intensity, operate the prodder carefully when the animals are wet.

III. How to charge the battery pack:

- Charge directly, you needn't take out the battery pack. Plug the Taragate electronic charger into the battery pack, connect to the AC power.
- The rechargeable battery is nickel cadmium (bubbling nickel). It has superior over-charge or discharge endurance, superior leakage resistance and extremely safe. Its cycle life is over 500 cycles under normal operations.
- The charger light will glow red when charging. When it turns green the unit is fully charged. Charging will take 8 - 10 hours.

IV. Notes for use:


- 1. This product is for farm animal use only. Keep out of reach of children.
- 2. The unit can be washed with water.
- 3. Do not submerge.
- 4. Do not discharge while in water.
- 5. Waterproof (IP45) under normal use.



The waterproof connections are as follows:

A, B, C & D: Rubber rings (waterproof connections)

E: Screw





Rechargeable **Prodder** 83 cm Shaft

Need help? We're here for you.

If you have questions or need advice, our friendly team is just a call or click away.

New Zealand: Shoof International Ltd. 224 Laurent Road North, Cambridge 3493. New Zealand, Ph 0800 800 801

Australia: Shoof International Ptv Ltd. 1 International Square, Tullamarine VIC 3043, Australia Ph 1800 121 801

Chile: Shoof International Chile Ltda. Regidor Gustavo Binder 1147, Bodega 3 v 4. Osorno, Chile, Ph 800 600 000

Shoof - we make caring for animals easier. www.shoofInt.com

Shoof and Taragate by Shoof are trademarks of Shoof International Ltd

Shoof Code: 224 644







Rechargeable **Prodder**

83 cm Shaft

- Flexible shatter-proof shaft
- High shock performance
- Safety switch to prevent accidental discharge
- No residual shock
- Rechargeable 12 v and 240 v

Instructions for the Taragate Rechargeable Prodder

I. Preparation before using:

- 1. Follow the user's manual when you operate a prodder.
- Choose the right shaft that allows you to keep a safe working distance from all livestock.
- 3. Check that all connections are clean and dry.
- 4. Insert the shaft into the handle and tighten the lock nut.
- Check that all the batteries are installed properly in the battery pack and that all connections are firmly fastened.

II. Operational Instructions:

- Turn the switch of the prodder to the "ON" position. Turn it "OFF" when not in use, to prevent accidental shock.
- To operate the prodder, press the button on the prodder, touch the rear of the animal with the two electrodes, the prodder releases effective electric shock, release the button. A light touch makes the most effective results.
- Because of potential for increase in intensity, operate the prodder carefully when the animals are wet.

III. How to charge the battery pack:

- Charge directly, you needn't take out the battery pack. Plug the Taragate electronic charger into the battery pack, connect to the AC power.
- The rechargeable battery is nickel cadmium (bubbling nickel). It has superior over-charge or discharge endurance, superior leakage resistance and extremely safe. Its cycle life is over 500 cycles under normal operations.
- The charger light will glow red when charging. When it turns green the unit is fully charged. Charging will take 8 - 10 hours.

IV. Notes for use:

- 1. This product is for farm animal use only. Keep out of reach of children.
- 2. The unit can be washed with water.
- 3. Do not submerge.
- 4. Do not discharge while in water.
- 5. Waterproof (IP45) under normal use.



The waterproof connections are as follows:

A, B, C & D: Rubber rings (waterproof connections)

E: Screw

