

Chick Warmer Covers



Features:

- Prevents chicks climbing onto the plate
- Protects the heating plate from damage
- Keeps the surface of the plate clean and hygienic

Product Information:

Optional clear domed-plastic cover (sold separately) prevents chicks climbing onto the

plate and creating a mess on it (see photos), and is available for each size warmer (except triangle units).

Code	Product
218 269	Chick Warmer 30×30cm Cover only
221 698	Chick Warmer 25×25cm Cover only
221 699	Chick Warmer 40×40cm Cover only
221 700	Chick Warmer 50×40cm Cover only
221 701	Chick Warmer 60×40cm Cover only
224 441	Chick Warmer Tri 40×40cm Cover only
224 442	Chick Warmer Tri 30×30cm Cover only