



Great value farming products

Rechargeable Prodder

- Flexible shatter-proof shaft
- High shock performance
- Safety switch to prevent accidental discharge
- No residual shock
- Rechargeable 12v and 240v

31cm
shaft



Great value farming products

Rechargeable Prodder
with 31cm shaft



Shoof Code: 224 642

Manufactured for:

SHOOF
INTERNATIONAL LTD

New Zealand:
Shoof International Ltd
Ph 0800 800 801
www.shoof.co.nz

Australia:
Shoof International
Pty Ltd
Ph 1800 121 801
www.shoof.com.au

Chile
Shoof International Chile Ltda
Ph 800 600 000
www.shoof.cl

User's Manual for Farmhand Rechargeable prodder

I. Preparation before using:

1. Follow the user's manual when you operate a prodder.
2. Choose the right shaft that allows you to keep a safe working distance from all livestock.
3. Check that all connections are clean and dry.
4. Insert the shaft into the handle and tighten the lock nut.
5. Check that all the batteries are installed properly in the battery pack and that all connections are firmly fastened.

II. Operational Instructions:

1. Turn the switch of the prodder to the "ON" position. Turn it "OFF" when not in use, to prevent accidental shock.
2. To operate the prodder, press the button on the prodder, touch the rear of the animal with the two electrodes, the prodder releases effective electric shock, release the button. A light touch makes the most effective results.
3. Because of potential for increase in intensity, operate the prodder carefully when the animals are wet.

III. How to charge the battery pack:

1. Charge directly, you needn't take out the battery pack. Plug the Farmhand electronic charger into the battery pack, connect to the AC power.
2. The rechargeable battery is nickel cadmium (bubbling nickel). It has superior over-charge or discharge endurance, superior leakage resistance and extremely safe. Its cycle life is over 500 cycles under normal operations.
3. The charger light will glow red when charging. When it turns green the unit is fully charged. Charging will take 8–10 hours.


IV. Notes for use:

1. This product is for farm animal use only. Keep out of reach of children.
2. The unit can be washed with water.
3. Do not submerge.
4. Do not discharge while in water.
5. Waterproof (IP45) under normal use.

The waterproof connections are as follows:

A, B, C & D: Rubber rings (waterproof connections)

E: Screw





Great value farming products

Rechargeable Prodder

- Flexible shatter-proof shaft
- High shock performance
- Safety switch to prevent accidental discharge
- No residual shock
- Rechargeable 12v and 240v

57cm
shaft



Great value farming products

Rechargeable Prodder
with **57cm shaft**



Shoof Code: 224 643

Manufactured for:

SHOOF
INTERNATIONAL LTD

New Zealand:
Shoof International Ltd
Ph 0800 800 801
www.shoof.co.nz

Australia:
Shoof International
Pty Ltd
Ph 1800 121 801
www.shoof.com.au

Chile
Shoof International Chile Ltda
Ph 800 600 000
www.shoof.cl

User's Manual for Farmhand Rechargeable prodder

I. Preparation before using:

1. Follow the user's manual when you operate a prodder.
2. Choose the right shaft that allows you to keep a safe working distance from all livestock.
3. Check that all connections are clean and dry.
4. Insert the shaft into the handle and tighten the lock nut.
5. Check that all the batteries are installed properly in the battery pack and that all connections are firmly fastened.

II. Operational Instructions:

1. Turn the switch of the prodder to the "ON" position. Turn it "OFF" when not in use, to prevent accidental shock.
2. To operate the prodder, press the button on the prodder, touch the rear of the animal with the two electrodes, the prodder releases effective electric shock, release the button. A light touch makes the most effective results.
3. Because of potential for increase in intensity, operate the prodder carefully when the animals are wet.

III. How to charge the battery pack:

1. Charge directly, you needn't take out the battery pack. Plug the Farmhand electronic charger into the battery pack, connect to the AC power.
2. The rechargeable battery is nickel cadmium (bubbling nickel). It has superior over-charge or discharge endurance, superior leakage resistance and extremely safe. Its cycle life is over 500 cycles under normal operations.
3. The charger light will glow red when charging. When it turns green the unit is fully charged. Charging will take 8–10 hours.


IV. Notes for use:

1. This product is for farm animal use only. Keep out of reach of children.
2. The unit can be washed with water.
3. Do not submerge.
4. Do not discharge while in water.
5. Waterproof (IP45) under normal use.

The waterproof connections are as follows:

A, B, C & D: Rubber rings (waterproof connections)

E: Screw





Great value farming products

Rechargeable Prodder

- Flexible shatter-proof shaft
- High shock performance
- Safety switch to prevent accidental discharge
- No residual shock
- Rechargeable 12v and 240v

83cm
shaft



Great value farming products

Rechargeable Prodder
with **83cm shaft**



9 417027 203733

Shoof Code: 224 644

Manufactured for:

SHOOF
INTERNATIONAL LTD

New Zealand:
Shoof International Ltd
Ph 0800 800 801
www.shoof.co.nz

Australia:
Shoof International
Pty Ltd
Ph 1800 121 801
www.shoof.com.au

Chile
Shoof International Chile Ltda
Ph 800 600 000
www.shoof.cl

User's Manual for Farmhand Rechargeable prodder

I. Preparation before using:

1. Follow the user's manual when you operate a prodder.
2. Choose the right shaft that allows you to keep a safe working distance from all livestock.
3. Check that all connections are clean and dry.
4. Insert the shaft into the handle and tighten the lock nut.
5. Check that all the batteries are installed properly in the battery pack and that all connections are firmly fastened.

II. Operational Instructions:

1. Turn the switch of the prodder to the "ON" position. Turn it "OFF" when not in use, to prevent accidental shock.
2. To operate the prodder, press the button on the prodder, touch the rear of the animal with the two electrodes, the prodder releases effective electric shock, release the button. A light touch makes the most effective results.
3. Because of potential for increase in intensity, operate the prodder carefully when the animals are wet.

III. How to charge the battery pack:

1. Charge directly, you needn't take out the battery pack. Plug the Farmhand electronic charger into the battery pack, connect to the AC power.
2. The rechargeable battery is nickel cadmium (bubbling nickel). It has superior over-charge or discharge endurance, superior leakage resistance and extremely safe. Its cycle life is over 500 cycles under normal operations.
3. The charger light will glow red when charging. When it turns green the unit is fully charged. Charging will take 8–10 hours.

IV. Notes for use:

1. This product is for farm animal use only. Keep out of reach of children.
2. The unit can be washed with water.
3. Do not submerge.
4. Do not discharge while in water.
5. Waterproof (IP45) under normal use.

The waterproof connections are as follows:

A, B, C & D: Rubber rings (waterproof connections)

E: Screw

